


Exploded view  
**Flex-2**



## Spare parts Flex-2

Art. no.	Description	0
0000102292	Spring for collar rotating hinge (Ultra)Flex	-
0000102293	Spring bracket for hose	-
0000102296	Aluminium fork M8	-
0000102307	Collar rotating hinge	-
0000102308	Tube holder (Ultra)Flex	-
0000102309	Plastic plug (Ultra)Flex (black)	-
0000102313	Rubber collar Ø 203 mm	-
0000102408	Knob for throttle valve RotaHood (2 pieces)	-
0050101100	Hose set Flex-2/T-Flex/CW	-
0703030380	Arm spring Flex-2 wall/unit side	-
0703030390	Spring hook Flex-2	-
0711010960	Threaded rod Flex-2	-
0711010970	Inner tube Flex-2 hood side	-
0711011020	Inner tube Flex-2 wall/unit side	-
0801850090	Arm section Flex-2/(Ultra)Flex-3	-
9823000000	RotaHood, complete	-
9823000100	Throat RotaHood, complete	-
9823000990	Throat RotaHood HD, complete	-
9823003000	RotaHood HD, complete	-
9824000010	Hinge set RotaHood, incl. protection cover	-
9824000040	Friction clamp Flex complete	-
9824000050	Rotating flange (Ultra)Flex	-
9824000100	Rubber protection cover hood hinge	-